

Maintenance Schedule

Maintenance Period Item	First 300km	1000km	2000km	3000km
Cylinder Head, Cylinder Nut	Check	Check	Check	Check
Air Filter	Clean every 300km		Replace	Replace
Tensioner	New car, and adjust every 1000km			
Valve Clearance	Check	Adjust	Adjust	Adjust
Fuel Filter	Clean	Clean	Clean	Clean
Spark Plug	Check	Check	Check	Replace
Engine Oil	every 300km in running-in period		Replace	Replace
Oil Filter	Clean	Replace	Replace	Replace
Oil Filter Screen	Clean	Clean	Clean	Replace
Carburetor	Check	Clean	Clean	Clean
Clutch	Check	Check	Check	Check

Note: Service more frequently when used in more severe conditions.